

# Töush

Inspired by Pensonic

## SMART DOOR LOCK

T8401SDL


Connecting Smart Devices with Smart Door Lock User Guide




Scan to  
download  
App

[www.pensonic.com](http://www.pensonic.com)

  
**1-800-881-770**  
call this number for any enquiries





#### Adding Administrator


1. First time user, long press "\*" on door lock pad. Voice prompt says "Please add administrator".
2. Set up administrator access using either finger print (same finger print 3 times), smart card or password (same password 2 times).
3. Voice prompt says "Add successful" when done.
4. To exit administrator setting press "\*" and to confirm setting press '#'.

#### Note:



1. For security purposes, please add 3 Administrators (The first 3 key-ins are administrator passwords)
2. Please add Administrator access before WiFi pairing.
3. Administrator access can either be fingerprint, smart card, or 6 to 8 digit password.
4. For finger print access, different positions of the fingerprint can be added to facilitate identification rate.
5. Press "\*" to go back or sign out and '#' to confirm settings.

- Note:
1. Ensure WiFi network is on before connecting device.
  2. The WiFi uses 2.4GHz waveband and works best with a strong and stable WiFi signal.
  3. If WiFi connection fails, restart WiFi router and repeat steps 1 & 2.




**Step 1** Turn on WiFi and connect to Internet.




**Step 2** If you do not have an account yet, kindly register by entering the required information.






**Step 3** Open Töush App, click on the '+' symbol to add product. Add Device > Security & Sensor > Lock (WiFi)



**Step 4** On door lock pad, press 3 and #, then key in administrator password. When number 8 on door lock pad blinks, press 'Confirm indicator blinking rapidly' on Töush App to complete pairing.



**Step 5** Now enter WiFi password.  
WiFi password > Confirm





 Note: Töush App must be installed on other device before product can be shared.


**Step 1** Click '' icon at the top right corner of Töush App home screen.



**Step 2** Click 'Share device'. Click on 'Add Sharing' option.



**Step 3** Enter another email address.



# Töush

Inspired by Pensonic

## KUNCI PINTU PINTAR T8401SDL


Panduan Pengguna Bagaimana Menghubungkan  
Peranti Pintar dengan Kunci Pintu Pintar




Imbas Untuk  
Muat Turun  
App

[www.pensonic.com](http://www.pensonic.com)

  
**1-800-881-770**  
call this number for any enquiries





#### Menambah Pentadbir


1. Untuk pengguna pertama kali, tekan panjang '\*' pada 'pad' kunci pintu. 'Prompt' suara akan berkata "Please add administrator".
2. Tambah akses pentadbir menggunakan sama ada cap jari (cap jari yang sama 3 kali), kad pintar atau katalaluan (katalaluan yang sama 2 kali).
3. 'Prompt' suara akan berkata "Add successful" apabila selesai.
4. Untuk keluar dari tetapan pentadbir tekan '\*' dan untuk mengesahkan tetapan tekan '#'.

#### Nota:



1. Untuk tujuan keselamatan, sila tambahkan 3 'Administrator' atau pentadbir (3 tambahan pertama adalah untuk pentadbir)
  2. Sila tambah akses Pentadbir sebelum penyambungan menggunakan WiFi.
  3. Akses pentadbir boleh dilakukan sama ada menggunakan cap jari, kad pintar, atau kata laluan 6-8 angka.
  4. Untuk akses cap jari, kedudukan cap jari yang berbeza boleh ditambah untuk memudahkan kadar pengenalan.
  5. Tekan '\*' untuk kembali atau keluar dan '#' untuk mengesahkan tetapan.
-

- Nota: 1. Pastikan rangkaian Wifi sudah diaktifkan sebelum menghubungkan peranti.  
2. Wifi ini menggunakan jalur gelombang 2.4GHz dan berfungsi dengan sempurna jika isyarat WiFi kuat dan stabil.  
3. Sekiranya sambungan WiFi gagal, cuba mulakan semula penghalang WiFi dan ulangi langkah-langkah 1 & 2.




**Langkah 1** Sambungkan Wifi dengan internet.




**Langkah 2** Jika anda belum mempunyai akaun, sila daftar akaun anda dengan mengisi maklumat yang diperlukan.




**Langkah 3** Buka 'Töush App', , klik pada simbol '+' atau 'Add Device' untuk menambah produk.  
Add Device > Security & Sensor > Lock (WiFi)



**Langkah 4** Di 'pad' kunci pintu, tekan '3' dan '#', kemudian masukkan katalaluan pentadbir. Apabila nombor '8' di 'pad' pintu mula mengelip, tekan 'tab' 'Confirm indicator blinking rapidly' pada App Töush untuk melengkapkan penyambungan.



**Langkah 5** Sekarang masukkan kata laluan WiFi.  
WiFi password > Confirm







Nota: 'Töush App' mesti di muat turun di peranti pintar yang lain sebelum perkongsian produk dapat dilakukan.

**Langkah 1** Klik ikon '✎' yang terdapat di sebelah kanan atas laman 'Töush App'.



**Langkah 2** Klik 'Share device' (Kongsi peranti).  
Klik pilihan 'Add Sharing' (Tambah).



**Langkah 3** Masukkan emel yang lain.

